



## ROSONI COMPLETI DI DRIVER CEILING ROSES COMPLETE WITH DRIVER

Rosone con driver per installazione a plafone - Testata di alimentazione art. 7344S/D non inclusa.

La scelta del rosone deve essere fatta sommando il carico dei prodotti utilizzati sul binario. Quest'ultimo è dato dalla somma dell'assorbimento della sorgente LED a quella dell'adattatore, 3W circa.

*Ceiling roses with driver for ceiling installation - Live end 7344S/D not included.*


*The choice of the ceiling rose must be made by adding the load of the products used on the track. The latter is given by the sum of the absorption of the LED source and that of the adapter, approximately 3W.*

### 0715/48

Rosone con driver  
Ceiling rose with driver  
IN: 220 - 240V  
OUT: 48V - 60W  
ON-OFF  
DIM 1...10V  
DIM PUSH

.01 Bianco - White  
.02 Nero - Black


**PUSH** **1...10V**



### 0716/48 0716/48/2

Rosone con driver con una o due uscite  
Ceiling rose with driver with one or two outputs  
IN: 220 - 240V  
OUT: 48V - 60W  
ON-OFF


.01 Bianco - White  
.02 Nero - Black



Installazione di testa al binario  
End to track installation



Installazione centrale tra due binari  
Central installation between two tracks



$L_{max} = A + B \leq 30 \text{ mt}$

**A** = Cavo di alimentazione  $2 \times 4 \text{ mm}^2$  - Power supply cable  $2 \times 4 \text{ mm}^2$

**B** = Binario - Track

P (W)	I (A)	L max
300	6,5	≤ 30mt
150	3,2	
75	1,6	

## ADATTATORE/ALIMENTATORE per sospensioni suspension ADAPTER/DRIVER



### 0987

IN: 48V  
OUT: 350mA DC  
Adattatore per binario 48V - 1 lampada  
Adapter for 48V track - 1 lamp

.01 Bianco - White  
.02 Nero - Black



EGOLUCE s.r.l. via I. Newton 12 - 20016 Pero - Milano  
telefono +39 02 339586.1 - fax. +39 02 3535112  
e-mail: info@egoluce.com - http://www.egoluce.com